

Joint TecTM

Your Paving - Our Passion

Advantages:

- Brush in
- Ready to use
- Water Permeable
- Weed/Frost Resistant
- Cement/Epoxy Free
- 24hr Walk Time

Available in:

5 Colours
15kg Buckets

Contact us:

www.jointtec.ie
www.jointtec.co.uk
info@jointtec.ie

Produced by Keltec Building
and Paving Products Ltd.



Joint TecTM

Your Paving - Our Passion

BRUSH IN PAVEMENT JOINTING COMPOUND

For Paving Slabs, Flags,
Natural Stone, Cobbles & Setts



We truly hope our passion shines through!

Joint Tec™

Your Paving - Our Passion

Ranges Available:



Why choose JointTec™ ?

JointTec™ - A world class brush in pavement jointing compound.

JointTec™ was developed with one main objective, to produce a jointing compound that not only saves on time and labour but also to produce a product that looks great and adds value to expensive paved areas.

Instructions for usage

Please follow the instructions carefully and if you have any further questions, check out our website on www.jointtec.ie and www.jointtec.co.uk

STEP 1 - PREPARATION

Ensure joints are clean, free from debris and a minimum of 20mm depth and 5mm wide. Narrower joints can be pointed with Joint Tec using the edge of a trowel or similar.



STEP 2 - WET AREA

Ensure the entire area to be pointed is thoroughly saturated with water prior to spreading Joint Tec. On a dry day ensure to keep re wetting the area.



N.B. It is essential all areas to be pointed are saturated in water prior to pointing and remain wet for the entire process.

STEP 3 - APPLY PRODUCT

Open the Joint Tec bucket and remove bag. Open the vac packed bag and pour Joint Tec onto areas to be pointed. Use in small manageable amounts, avoid spreading over a large area before application.



STEP 4 - WORK INTO JOINTS

With a stiff brush or squeegee brush Joint Tec into all joints, ensuring all joints are filled and compacted.



STEP 5 - CONTINUOUSLY WASHING

With a hose on sprinkle, add more water to help residual compound flow into the joints of the paving and to aid the final compaction process.



STEP 6 - FINAL WASH AND CLEAN

Apply a final gentle spray of water across the surface to wash off any Joint Tec residue. Always sweep with a clean brush diagonally across joint to remove any loose grains. Take care not to brush product out of joints or into nearby drains.



STEP 7 - SMOOTH THE JOINTS

It is not essential but we do recommend to 'strike' or 'point' the surface of the joints with a suitable pointing tool. This will ensure the joints are all below the surface of the paving, resulting in a perfect finish to your paving.

